

ADDENDUM

CABLE LASH INITIALIZATION

After initial installation of the Cruise Control Kit, any time the cruise control cable is disconnected on either end, or if the idle speed is adjusted, you **must** use the following procedure to adjust the cruise control cable slack. Failure to do so will adversely affect the operation of the cruise control.

1. Warm motorcycle up to operating temperature and shut ignition switch off.
2. Set cruise control on/off switch to the "On" position
3. Set right hand run/off switch (kill switch) to the "Run" position.
4. **Hold** the set/resume switch in the "Resume" position (do not release until instructed to do so).
5. Turn the ignition switch to "On" position.
6. While continuing to hold the set/resume switch in the "Resume" position, start motorcycle.
7. When the motorcycle has started, the green cruise control indicator lamp will illuminate for 3 seconds. When indicator lamp shuts off release the set/resume switch.
8. Again, **hold** the set/resume switch to the resume position. The green cruise control indicator lamp will illuminate while cruise control unit is adjusting cruise control cable slack. You will hear motor noise from the cruise control module and the engine will speed up slightly momentarily.
9. Once cruise control unit has detected an increase in engine rpm, the green indicator lamp will shut off. When the green indicator lamp shuts off release set/resume switch and shut off motorcycle. The slack adjustment has been completed.